

ITEM 935

STREET SWEEPING AND VACUUMING

- 935.1 Description. Practices used to remove tracked sediment to prevent the sediment from entering a storm drain or watercourse.
- 935.2 When BMP is to be installed. Anytime sediment/silt has been tracked from the site onto public or private paved surfaces.
- 935.3 Appropriate Applications. These practices are implemented anywhere sediment is tracked from the project site onto public or private paved roads, typically at points of ingress/egress.
- 935.4 Performance. Sweeping and vacuuming may not be effective when soil is wet or muddy.
- 935.5 Standards and Specifications. Visible sediment tracking should be swept and/or vacuumed daily. Adjust brooms frequently to maximize efficiency of sweeping operations. Be careful not to sweep up any unknown substance or any object that may be potentially hazardous. If not mixed with debris or trash, consider incorporating the removed sediment back into the project. After sweeping is finished, properly dispose of sweeper wastes at an approved dumpsite. **Do not wash any sediment or debris down the storm drain!**
- 935.6 Operations and Maintenance. Inspect ingress/egress access points daily and sweep tracked sediment as needed, or as required.
- 935.7 Site Condition for Removal. NA

END OF ITEM 935